


- LS#41 STORAGE
- LS#40 BLACK SCRM
- LS#38 REAR TRAVELLER
- LS#38 CYC
- LS#37
- LS#36 US TABS
- LS#35
- LS#34
- LS#33
- LS#32 CYC ELEC
- LS#31 ELEC#3
- LS#30 LEGS#3
- LS#29 BORDER#4
- LS#28
- LS#27
- LS#25
- LS#24 ORCH SHELL#3
- LS#23
- LS#22
- LS#21 US TRAVELLER
- LS#20
- LS#19 ELEC#2
- LS#18 BORDER#3
- LS#17
- LS#16 ORCH SHELL#2
- LS#15 LEGS#2
- LS#14
- LS#13
- LS#12 BORDER#2
- LS#11 DS TABS
- LS#10
- LS#9
- LS#8
- LS#7 ORCH SHELL#1
- LS#6 LEGS#1
- LS#5
- LS#4 ELEC1
- LS#3 BORDER#1
- LS#2 MAIN CURTAIN
- LS#1 HEADER/SCREEN


Leshler Center for the Arts
 1601 Civic Drive Walnut Creek CA 94596
 (925) 295.1400 leslerartscenter.org

Hofmann Theatre Floor Plan

Revised 08/09
 By: 76

Scale: 1/4" = 1'
